

**SHERWIN
WILLIAMS.****SUPERPAINT®**
Exterior Latex FlatA80W00116 Super White
A80W01151 Extra White
A80W00153 Deep Base
A80T01154 Ultradeep Base
A80Y00156 Light Yellow

As of 03/08/2018, Complies with:

OTC	Yes	LEED® 09 NC CI	N/A
OTC Phase II	Yes	LEED® 09 CS	N/A
SCAQMD	Yes	LEED® v4 Emissions	N/A
CARB	Yes	LEED® v4 VOC	Yes
CARB SCM2007	Yes		
Canada	Yes	MPI	Yes

CHARACTERISTICS

SuperPaint Exterior Latex Flat, with resistance to early dirt pick up, provides outstanding performance on properly prepared aluminum and vinyl siding, wood, hardboard, masonry, cement, brick, block, stucco, and metal down to a surface and air temperature of 35°F.

VinylSafe™ paint colors allow you the freedom to choose from 100 color options, including a limited selection of darker colors formulated to resist warping or buckling when applied to a sound, stable vinyl substrate.

Color: Most colors
To optimize hide and color development, always use the recommended P-Shade primer

Coverage: 350 - 400 sq ft/gal
@ 4 mils wet; 1.4 mils dry

Drying Time, @ 50% RH:
@ 35-45°F @ 45°F+
Touch: 2 hour 2 hours
Recoat: 24-48 hours 4 hours

Drying and recoat times are temperature, humidity, and film thickness dependent

Finish: 0-5 units @ 85°

Tinting with CCE:

Base	oz/gal	Strength
Extra White	0-6	SherColor
Deep Base	4-12	SherColor
Ultradeep Base	10-12	SherColor
Light Yellow	2-12	SherColor

Extra White A80W01151
(may vary by base)

VOC (less exempt solvents):
<50 g/L; <0.42 lb/gal

As per 40 CFR 59.406 and SOR/2009-264, s.12

Volume Solids: 36 ± 2%

Weight Solids: 53 ± 2%

Weight per Gallon: 11.38 lb

Flash Point: N/A

Vehicle Type: 100% Acrylic

WVP Perms (US) 33.14
grains/(hr ft² in Hg)

Mildew Resistant

This coating contains agents which inhibit the growth of mildew on the surface of this coating film.

SPECIFICATIONS

SuperPaint Exterior Latex Flat can be self-priming when used directly over existing coatings, or bare drywall, plaster and masonry (with a cured pH of less than 9). The first coat acts like a coat of primer and the second coat provides the final appearance and performance. Please note that some specific surfaces require specialized treatment.

**Aluminum & Aluminum Siding¹,
Galvanized Steel¹, Vinyl Siding**

2 cts. SuperPaint Exterior Latex

Concrete Block, CMU, Split Face Block

1 ct. Loxon Block Surfacers

2 cts. SuperPaint Exterior Latex

Brick

1 ct. Loxon Conditioner²

2 cts. SuperPaint Exterior Latex

Cement Composition Siding/Panels

1 ct. Loxon Concrete & Masonry Primer²

or Loxon Conditioner²

2 cts. SuperPaint Exterior Latex

Stucco, Cement, Concrete

1 ct. Loxon Concrete & Masonry Primer²

2 cts. SuperPaint Exterior Latex

Plywood

1 ct. Exterior Latex Wood Primer

2 cts. SuperPaint Exterior Latex

Wood (Cedar, Redwood)³

1 ct. Exterior Oil-Based Wood Primer²

2 cts. SuperPaint Exterior Latex

¹ On large expanses of metal siding, the air, surface, and material temperatures must be 50°F or higher.

² Not for use at temperatures under 50°F. See specific primer label for that product's application conditions.

³ Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. For best results on these woods, use a coat of Exterior Oil-Based Wood Primer.

Other primers may be appropriate. Standard latex primers cannot be used below 50°F. See specific primer label for that product's application conditions.

When repainting involves a drastic color change, a coat of primer will improve the hiding performance of the topcoat color.

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Scrape and sand peeled or checked paint to a sound surface. Sand glossy surfaces dull. Seal stains from water, smoke, ink, pencil, grease, etc. with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Aluminum and Galvanized Steel

Wash to remove any oil, grease, or other surface contamination. All corrosion must be removed with sandpaper, wire brush, or other abrading method.

Caulking

Gaps between windows, doors, trim, and other through-wall openings can be filled with the appropriate caulk after priming the surface.

Cement Composition Siding/Panels

Remove all dirt, dust, grease, oil, loose particles, laitance, foreign material, and peeling or defective coatings. Allow the surface to dry thoroughly. If the surface is new, test it for pH, if the pH is higher than 9, prime with Loxon Concrete & Masonry Primer.



102.01

SUPERPAINT®

Exterior Latex Flat

A80W00116 Super White
A80W01151 Extra White
A80W00153 Deep Base
A80T01154 Ultradeep Base
A80Y00156 Light Yellow

SURFACE PREPARATION

Masonry, Concrete, Cement, Block

All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete & Masonry Primer. Cracks, voids, and other holes should be repaired with an elastomeric patch or sealant.

Steel

Rust and mill scale must be removed using sandpaper, wire brush, or other abrading method. Bare steel must be primed the same day as cleaned.

Stucco

Remove any loose stucco, efflorescence, or laitance. Allow new stucco to cure at least 30 days before painting. If painting cannot wait 30 days, allow the surface to dry 7 days and prime with Loxon Concrete & Masonry Primer. Repair cracks, voids, and other holes with an elastomeric patch or sealant.

***Vinyl or other PVC Building Products**

Clean the surface thoroughly by scrubbing with warm, soapy water. Rinse thoroughly, prime with appropriate white primer. Do not paint vinyl with any color darker than the original color or having a Light Reflective Value (LRV) of less than 56 unless VinylSafe® Colors are used. If VinylSafe colors are not used the vinyl may warp. Follow all painting guidelines of the vinyl manufacturer when painting. Only paint properly installed vinyl siding. Deviating from the manufacturer's painting guidelines may cause the warranty to be voided.

Wood, Plywood, Composition Board

Clean the surface thoroughly then sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. All new and patched areas must be primed. Knots and some woods, such as redwood and cedar, contain a high amount of tannin, a colored wood extract. If applied to these bare woods, it may show some staining. If staining persists, spot prime severe areas with 1 coat of Exterior Oil-Based Wood Primer prior to using.

SURFACE PREPARATION

Mildew

Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.

Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.

APPLICATION

When the air temperature is at 35°F, substrates may be colder; prior to painting, check to be sure the **air, surface, and material temperature** are above 35°F and at least 5°F above the dew point. Avoid using if rain or snow is expected within 2-3 hours.

Do not apply at air or surface temperatures below 35°F or when air or surface temperatures may drop below 35°F within 48 hours.

No reduction necessary.

Brush

Use a nylon/polyester brush.

Roller

Use a 3/8" - 3/4" nap synthetic cover.

Spray—Airless

Pressure 2000 psi

Tip015"-.019"

CAUTIONS

For exterior use only.
Protect from freezing.
Non-photochemically reactive.
Not for use on floors.

Before using, carefully read **CAUTIONS** on label.

HOTW 03/08/2018 A80W01151 33 38

KOR, FRC, Viet

CLEANUP INFORMATION

Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with a compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit www.paintdocs.com to obtain the most current version of the PDS and/or an SDS.